

# DAYTONA BY TRIKE

## *Power Trak*

### Installation Instructions

Revised 1 - 10

- 1 - Upper Triple Clamp
- 1 - Lower Triple Clamp
  - 1 - Steering Stem
  - 1 - Dust Seal, Steering Stem
  - 1 - Lower Bearing set
- 4 - 3/8 - 16 X 2 1/2 socket head cap screw
- 4 - 1/4 - 28 x 1 1/2 socket head cap screw
- 2 - Fork Tube Extensions
- 2 - Fork Tube Extension Caps
- 2 - Adjusting Nuts
- 1 - Jam Nut
- 2 - Steering Stops
- 2 - 10-32 x 1/2 Phillips head cap screw

ALL ORDERS ARE TO BE DOUBLE  
CHECKED TO ELIMINATE SHIPPING  
ERRORS.

FILLED BY: \_\_\_\_\_

CHECKED/PACKED BY: \_\_\_\_\_

For installation assistance, call Parts & Technical support @ 434.263.8866

## **Warnings and considerations:**

- 1.Disclaimer** - These instructions assume a level of understanding of motorcycle repair and maintenance beyond that of a “beginner” and/or “novice” and California Sidecar cannot be liable for an installer’s failure to understand or follow these instructions as written. Likewise, California Sidecar cannot be responsible if any of the steps are omitted or shortcuts are taken, or parts other than those supplied by California Sidecar are used.
- 2.“WARNINGS”** are all printed in bold type and capitalized. They mean to use extreme care in a given step so as not to damage the part, motorcycle, and/or yourself.
- 3.Always** wear safety glasses when using hand and/or power tools.
- 4.**When working in and around the fuel system, **always** work in a well-ventilated area, free from sparks and open flames.
- 5.**All directional references to the “right side” and the “left side” are as you were seated on the motorcycle.
- 6.**All directional references to “forward” mean to the front of the motorcycle while “back” means the rear of the motorcycle unless otherwise stated.
- 7.Warning:** The fork spring cap is under spring pressure; use care when removing it.

**Special tools:**

1. Bearing adjustment nut socket.

**Disassembly:**

1. Refer to the Service Manual for the model Motorcycle that you are working on for disassembly.

**Fork tube extension installation:**

1. Remove stock fork cap and install CSC fork tube extension. Reuse stock o-rings from the caps and from the bolts. Torque to spec.

**Power Trak Triple Clamp Installation:**

1. Install the new lower triple clamp after greasing lower bearing. Use multi purpose grease. Install top bearing and adjuster nut and torque to spec. (30 Ft.-Lbs.)
2. Finger tighten jam nut and install top triple clamp.
3. Install top nut snug with socket.
4. Install fork tubes and refer to service manual for tightening and torque procedures for the triple clamps and fork tube pinch bolts.
5. Torque top nut to spec. (80 Ft.-Lbs.)

**2009 and UP Models only**

6. Install two steering stops into top triple clamp with two 10-32 x 1/2 Phillips. The stops should hang down.

**NOTE: The ignition switch may need modified. Install carefully.**

7. Assemble in reverse order.

**From all of us at California Sidecar.  
Enjoy the ride!**