

Vantage

BY **csc** TRIKES

ELECTRIC REVERSE

INSTALLATION INSTRUCTIONS WITH TRIKE KIT

1.) ELECTRICAL

- 1 - Electric Reverse Control Module
- 2 - Wiring Harness
 - 1 - Reverse Button
- 1 - Cable Set (1 Red, 1 Black)
- 1 - Terminal Boot
- 4 - Scotch lock connector
- 2 - Butt connector
- 1 - 21" Cable Tie

**ALL ORDERS ARE DOUBLE
CHECKED TO ELIMINATE
SHIPPING ERRORS.**

FILLED BY: _____

CHECKED & PACKED BY: _____

Warnings and considerations:

1. **Disclaimer** - These instructions assume a level of understanding of motorcycle repair and maintenance beyond that of a “beginner” and/or “novice” and California Sidecar cannot be liable for an installer’s failure to understand or follow these instructions as written. Likewise, California Sidecar cannot be responsible if any of the steps are omitted or shortcuts are taken, or parts other than those supplied by California Sidecar, are used in installing this trike kit.
2. **“WARNINGS”** are all printed in bold type and capitalized. They mean to use extreme care in a given step so as not to damage the part, motorcycle, and/or yourself.
3. **Always** wear safety glasses when using hand and/or power tools.
4. When working in and around the fuel system, **always** work in a well-ventilated area, free from sparks and open flames.
5. All directional references to the “right side” and the “left side” are as you were seated on the motorcycle.
6. All directional references to “forward” mean to the front of the motorcycle while “back” means the rear of the motorcycle unless otherwise stated.
7. Please consult the appropriate Service Manual for your motorcycle if further detail is necessary.


INSTALL REVERSE AND ALL ITS PARTS DURING INSTALLATION AND BEFORE THE BODY IS INSTALLED.

Assembly:

1. Once 37 MM and 50 MM belts are tensioned and all clamping bolts are tightened.
2. Check the Tension of the Reverse belt.
3. Sonic Tension Meter specs:
MASS 004.7
WIDTH 021.0
SPAN 0213
4. Reverse Belt Tension:
SINGLE SPAN TENSION: 49-55 lbs.

Wiring:

1. Locate the large starter relay behind the seat with the 16 pin connector.




Use this
relay
box

2. Route the blue, white/blue, green, and brown wires to it.
3. Locate the light blue wire with white tracer (Neutral light wire) connect it to the brown wire using a scotch lock connector.

4. Locate the red wire with blue tracer (Engine run wire) connect it to the green wire using a scotch lock connector.
5. Locate the blue wire with white tracer (Start button wire) and cut it.
6. Connect that blue wire with white tracer at the relay to the white wire with blue tracer with a butt connector.
7. Connect the other end of that blue wire with white tracer that goes to the harness to the blue wire with a butt connector.
8. Set the rest of the harness on top of the battery area and continue with the trike installation.

Wiring continued: (after the suspension is installed)

1. Secure Reverse module to Rear Mount Plate with cable ties turned 90°.





2. Plug both harnesses into the Reverse module.
3. Route the blue and white wires to the Reverse motor.
4. Route the two red wires to the battery area.
5. Route the long wire harness up under the seat.
6. Remove the left side chrome engine cover. Using a 1/2 inch drill bit. Drill thru the cover. Refer to picture.



Place
Reverse
Switch
Here

- 7. Ensure the rubber washer is on the Reverse switch, then insert the wire thru the cover and install nut and tighten.**
- 8. Connect the harness to the Reverse switch and secure wires with cable ties. Reinstall the chrome cover.**
- 9. Locate the yellow wire (brake light) under the seat at the fender plug. Using a scotch lock, connect to the red/yellow wire.**
- 10. Locate the blue wire (tail light) under the seat at the fender plug. Using a scotch lock, connect to the red wire.**
- 11. Install terminal boot onto red positive cable.**
- 12. Connect the red positive cable to the stud on the Reverse motor solenoid.**
- 13. Using provided cable tie, secure the positive cable to the Reverse motor.**
- 14. Install the black negative cable and white wire to the lower long mounting bolt on the Reverse motor. Route the negative cable to the battery.**
- 15. Connect the blue wire to the male spade on the Reverse motor.**
- 16. Connect the red cable to the positive battery terminal and the black cable to the negative battery terminal.**
- 17. Ensure that all wires and miscellaneous components are secured to the frame with cable ties.**

Operating the Electric Reverse:

- 1. With the Trike in neutral. Start the engine.**
- 2. Depress the reverse switch and the red LED will light up.**
- 3. Press the start button and the trike will then back up.**
- 4. If the brakes are applied the reverse will pause until the brakes are no longer being used.**

**From all of us at California Sidecar.
Enjoy the ride!**